
Creating a Quarks Application April 13, 2016



Apache Quarks is currently undergoing Incubation at the Apache Software Foundation.

Quarks – The Connected Perspective



- Quarks communicates through connectors to relay data to a central analytics cluster (Spark, IBM Streams)
- Quarks provides several of these:
 - Watson Internet of Things (MQTT with device registration)
 - Kafka
 - JDBC
 - (and more!)
- We are primarily concerned with Watson IoT
 - Easy to set up
 - Integrates well with BlueMix

Creating a Watson IoT Device - BlueMix





BlueMix has a free Watson IoT service

Creating a Watson IoT Device - Service



- Create a BlueMix account.
- Create a Watson IoT Service
 - Create a device. Record its access token.
 - Create an API Key. Record its token.
- Using the tokens, create the device.conf file. This will be used to connect to Watson IoT, for example:

```
org=9wmrlu
type=RaspberryPi
id=Pi-001
auth-method=token
auth-token=Ro?2(pcQARJhrj5erprwGcE
```



```
public static void main(String[] args) throws Exception {
}
```

• Starting from main...



```
public static void main(String[] args) throws Exception {
    String deviceCfg = "device.cfg";
}
```


Keep track of the path to your device's config file.



- Using the config file, create a new IoTProvider object.
- The IoTProvider takes a function that creates an IotfDevice object given a topology as a parameter.



• This function is used to create a Quarks Application which talks to the Watson IoT message hub through the created IotfDevice.






The IoTProvider allows the user to register functions which build an application.



• When invoked, this function takes the iotDevice and uses it to construct an application which sends a heartbeat message to the central analytics cluster every minute.



With the IotfDevice and the heartbeat messages the scenario looks like this:





- Similarly, we can register a function which, when invoked, creates an application that simulates sensor readings and sends them to the central analytics cluster.
- These are two separate applications



With the IotfDevice, the heartbeat messages, and the sensor readings, the scenario looks like this:

